Technical Specifications:

Measurements (LWH): 105mm x 73mm x 60mm Weight (grams): 125g

Operational Voltage: 3.7v Operational Current: < 10mA

Sleep Current: < 1uA Sensitivity: 4 DPI modes: 1000-1600-3200-6400 DPI

Computer Requirements

- -Windows 2000
- -Windows XP
- -Windows Vista, Windows CE, Windows 7, Windows 10.
- -Linux
- -Android
- -Mac OSX

Maintenance and Care Instructions

Do not attempt to open the device or remove one or more of its components. Doing so will make the warranty invalid and may cause the product to short circuit; causing a fire or explosion.

Use only a damp cloth with mild soap to clean the device. Solvents and other abrasive cleaners may cause damage to the device.

Don't expose the device to very hot or cold environments. Extreme temperatures can shorten the life of the device.

Troubleshooting

The following are some common troubleshooting scenarios and possible solutions. For any other questions please contact us at support@anthrodesk.ca

Problem	Possible Reason	Possible Solution
The mouse is not responsive or moves too fast.	1. The mouse DPI is set too low or too high.	1. Switch your mouse's DPI to a more comfortable setting.
The mouse is not being detected by the computer	1. The USB port on the computer is not working or there is a problem with the mouse.	1. Disconnect the mouse and connect it to a different USB port. If it is still not detected, contact support.

Mouse Buttons



- Left-click mouse button
- Right-click mouse button
- Scroll wheel / Middle-click button
- Forward button
- Back button
- DPI Button

DPI Adjustments

To adjust your mouse's DPI, press the "DPI" button to cycle between the options. You can use the table below as a guideline to adjust to your preferred setting.

Color	DPI
Green	1000
Pink	1600
Blue	3200
Red	6400



AnthroDesk Wired Vertical Mouse

The AnthroDesk vertical mouse will allow you to work more comfortably and will help you lead a healthy lifestyle. Because of its innovative shape, the vertical mouse will help prevent common arm and wrist injuries associated with the strain of working at a computer for extended periods of time.

Vertical Mouse User Manual



