


# Ergonomic Wobble Chair

## ■ ASSEMBLY INSTRUCTIONS:


### STEP 1:

Remove & discard the red plastic cap covering the tip of the gas spring:




### STEP 2:

Insert the gas spring (C) into the base (D). Once aligned correctly, press down firmly




### STEP 3:

Connect the Plastic Collar (B) to the Seat (A) by resting the Seat on the cushion and firmly pressing the Plastic Tube against the seat.



### STEP 4:


Gently slide the seat onto the gas spring. Once aligned properly, press down firmly on the seat.



**WARNING!** The red plastic cap must be removed before use. Failure to remove it will make Wobble Chair malfunction.

## ■ OPERATING INSTRUCTIONS:

1. To raise the seat, gently press any 1 of the 3 underseat buttons.
2. To lower the seat: Gently press any 1 of the 3 underseat buttons and simultaneously press down on the seat (or sit on the seat).




**TIP!** If the seat does not raise easily:


1. Be sure the red plastic cap on top of the gas spring has been removed.
2. If Wobble Chair is assembled correctly, add additional pressure to the seat by pushing down or sitting on it to secure the connection for proper use.

## ■ SITTING INSTRUCTIONS:

1. Wobble Chair's base is unstable. Wobble Chair rocks, tilts, tips and the seat swivels 360°. It is not a stationary chair. Extreme care must be used when sitting on the Wobble Chair.



2. Only sit on Wobble Chair if both of your feet are planted firmly on the ground supporting your entire bodyweight.



**WARNING! DO NOT LEAN BACK.** To reduce fall risk, do not tip Wobble Chair past vertical.  
**WARNING!** Not for use by children.  
**WARNING!** Do not use with only 1 foot or no feet on the ground.